

Instruction for windows mobile

Brief introduction

The documents mainly introduces how to set and use the Software for windowmobile OS.

The Software has some main functions.

- 1) Browse real time video function
- 2) Cloud stand control function(the front end is to control ball machine)

Essential condition

Favor windowmobile system 2003 releases and it is above.Favors to touch to hold release just currently

Install and operating instructions

- 1) Pass TMEyesetup.cab data wire to make duplicate the hand of window mobile on board




- 2) Find out TMEyesetup.cab under the appointed catalog, double click a progress setup, after










finishing installing under the procedure(Programs) path will appear a routing diagram mark, the following chart








- 2) Click pairs in response to routing diagram mark, circulate a beginning to start interface the following chart after the procedure



Press button versus in response to the function is as follows

Function key	name	Function describe
	start	The procedure connectivity equipment combines to start broadcasting a video
	setting	Establish a DVR IP address or watch an area, port, user's name and password and equipment alias information
	stop	The procedure breakup broadcasts a video
	Select gateway	Select a some video of one gateway that broadcasts an equipment
	PTZ control	Carry out a cloud on the stage, next, left and right control
	Zoom ratio	The realize tension far draws near
	focus	Carry out focal length to add and subtract
	aperture	Carry out diaphragm to add and subtract
	snap	Grasp to clap a current ICON(grasp a chart document conservancy to arrive the photo catalog of installing the catalog down the following chart)

	record	11-3-23 172B
	amplayer	11-3-19 222K
	camera	11-3-9 8.09K
	photo	
	skin	

3) **Setting**:

Such as first time use or need to carry on parameter to change, please click button to enter a parameter setup interface. The following chart

The screenshot shows a parameter setup interface with the following elements:

- Username:** A dropdown menu.
- Password:** A text input field.
- Server:** A text input field.
- Port:** A text input field.
- Notes:** A text input field containing the text "MyDVR".
- Buttons:** "Ok", "History", "Photo folder", and "Auto Connect" (with an unchecked checkbox).

explain

User's name (User name): The user's name reconciliation that carries a setup with IE

Password (Password): The password reconciliation that carries a setup with IE

Server address (Server): DVR male net IP address or dynamic state area

Server port (Port): DVR up the server port of setup

Equipment denomination (Notes): The present of equipment is easy to classify several equipments

Photo folder

Click button to enter to grasp chart conservancy catalog



Click button to enter to grasp chart conservancy catalog

Server	Port	Note
		MyDVR
		MyDVR



Pick out the record that to delete, at press Delete button and then can recording to carry on a delete operation vs the

Pick out a certain record to click[OK]the button can return to establish an interface

Username:

Password:


Server:

Port:

Notes:

☐ Auto Connect

Again click[validation]button enter to link an interface



Wait to create a connectivity success and then will enter to broadcast menu

The video displays mode

Down the routine mode and full plate mode progress cuts over

Normal mode



Disconnect

Clicking the button can stop watching


Full screen

While by hand pointing or touching an one - shot to broadcast menu will cut over full plate to broadcast



The full plate broadcasts the one - shot in time to broadcast menu cutover to return to routine to broadcast mode

4) Switch channel



Click to down pull to press button

Pick out homologous gateway, the procedure will open homologous gateway to combine to automatically broadcast a video

The DVR parameter that favors a cellular phone establishes a reference

Resolution: CIF or QCIF

Leads: 5-10

The code flows a type: Limit

The code flows: 64-256Kb/S

Note: Can carry on tune according to the cellular phone performance and the network condition. Higher cellular phone performance and network condition can display better effect. If the network condition is worse, can appropriately the step - down lead and assure flowing freely