

instruction for Blackberry

1. Brief introduction

The documents mainly introduces how to set and use the Software for Android OS.

The Software has some main functions.

- 1) Browse real time video function
- 2) Cloud stand control function(the front end is to control ball machine)

Essential condition

Favor Blackberry system more than 4.6 releases, the cellular phone screen resolution has for 480*360, 480*320, 360*480, 320* being 240 cellular phones, accounting:8520, 8900, 9000, 9700, 9630, 9530, 9500, 9800 etc.s, the release of blackberry needs to brush into special release to watch effect to be better

Concrete details

The 8520/8900/9000 needs system 5.0.0.90


9700 requirement systems 5.0.0.714 or 5.0.0.344

The 9630/9530/9500/9800 needs system 6.0.0.284


Install and operating instructions

1)

Install TMEye.cod and TMEye.alx to wrap to pass a table's top supervision a machine to pack into a Blackberry cellular phone, the following chart



2) click "options" of cellular phone table's top, enter to is shown as chart below a



page

3) click "application procedure", find out TMEye, click into, click "edit extent of authorith", establish all extent of authoriths in order to "allow", if having parts of extent of authoriths can not establish in order to "allow" (the picking is gray, can not change), don't need to be realized, directly click to keep all right

4) Click TMEye routing diagram the mark , after circulating procedure, start to turn after a

beginning of Shan plate interface, enter a beginning to start an interface, the following chart

Setting

Sever info

Title:

company

Address:

Port:

User info

User ID:

Password:

Network info

Network type:

WIFI ▼

Login

Cancel

DeviceList

explain

Equipment header(Title):The alias of equipment is easy to classify several equipments

Server address(Address):DVR male net IP address or dynamic state area

Server port(Port):DVR up the server port of setup



User's name(User ID):The user's name reconciliation that carries a setup with IE

Password(Password):The password reconciliation that carries a setup with IE


Network type(Network Type):Select you wants the network type of use

Press button vs in response to the function is as follows












Function key	name	Function describe
<div>Login</div>	Logging in	Enter to broadcast lord interface, the procedure connectivity equipment combines to start broadcasting a video

	cancel	Program exit
	Device list	Enter an equipment record page


5) click an entry, broadcast a lord interface



Press button vs in response to the function is as follows

Function key	name	Function describe
	play	The procedure connectivity equipment combines to start broadcasting a video
	Full screen	Full screen playing
	snap	Grasp to clap a current ICON(grasp a chart document to recognize tacitly conservancy to the cellular phone of tacit approval of photograph catalog down
	setting	Establish a DVR IP address or watch an area, port, user's name and password and equipment alias information
	Next group	Can select to descend gang gateway
	about	About information
	Select gateway	Can select to descend gang gateway
	Ptz control	Carry out a cloud on the stage, next, left and right control
	Zoom control	The realize tension far draws near
	focus	Carry out focal length to add and subtract
	aperture	Carry out focal length to add and subtract


6) Carry out focal length to add and subtract



7) click "equipment tabulator", enter a history tabulator, the following chart

Device List	
DeviceTitle:Admin	
DeviceTitle:company	
DeviceTitle:admin	

Click menu key, flick menu open, the following chart



Click menu key, flick menu open, the following chart

Function key	name	Function describe
open	play	Click menu key, flick menu open, the following chart
New device	new	Lately set up a new record
edit	edit	Edit record

Clear record conservancy path	clear	clearClearance keeps path(grasp the chart picture conservancy path)
delete	delete	The delete picks out a record
Delete all records	Delete all	Delete all records

The cutover applies procedure	switch	Cutting over is another of applied procedure
close	close	Close procedure

5) The video displays mode

Down the routine mode and full plate mode progress cuts

Regular mode



Full screen mode



The DVR parameter that favors a cellular phone establishes a reference

Resolution: CIF

Leads: 5-1

The code flows a type: Limit

The code flows: 64-256Kb/S

Note: Can carry on tune according to the cellular phone performance and the network condition. Higher cellular phone performance and network condition can display better effect. If the network condition is worse, can appropriately the step - down lead and assure flowing freely